


SINGLE BOX CALIBRATION

NOTE. Start all calibration with the display showing 


 - When pressed increases the figures up in tens or hundreds.


 - When pressed decreases the figures down in .ones or ones.

PRIME SYSTEM

PLACE seed collecting trays in position under all the sponges.



PRESS  To show  on the display.


PRESS  Motor will start to dispense seed.


PRESS  To stop dispensing seed when seed appears at all outlets.


EMPTY trays back into bins and replace them under all the sponges. **You are now ready to calibrate.**

TO CALIBRATE SYSTEM

PRESS  To show  on the display.


PRESS  Motor will start to dispense seed.


PRESS  To stop dispensing seed when there is a good amount of seed in the tray to weigh.

Generally any number over  on the display is good.


WEIGH the seed collected. (The Taeye supplied scales read in grams. Check switch under scales is set to gm)


PRESS  Display shows 

PRESS  to enter weight up in 100 gram increments.

PRESS  to decrease the weight in 1 gram increments.

PRESS  Display shows a figure which is the last entered seeding target rate in Kg Ha.

PRESS  to increase target rate in 10 Kg Ha increments.

PRESS  to decrease the target rate in .1 Kg Ha increments.

PRESS  Display shows  and you have completed calibration.

PRESS  Display shows  momentarily then a number. **You are ready to go.**

SINGLE BOX TARGET SEEDING RATE ALTERATION.

NOTE. Start all calibration with the display showing

OFF

DIST

- When pressed increases the figures up in tens or hundreds.

SPEED

- When pressed decreases the figures down in .ones or ones.

PRESS **ON/OFF** To show **OFF** on the display.

PRESS **CAL 2** 4 times. Display shows **P4**

PRESS **DIST** Display shows your current seeding rate in Kg/Ha

PRESS **DIST** to increase in increments of .100 or **SPEED** to decrease in increments of .01.

PRESS **CAL 2** 2 times. Display shows **OFF**

PRESS **ON/OFF** Display shows **ON** momentarily then a number.

YOU ARE NOW READY TO GO.

HECTARE / DISTANCE / SPEED METER

Your electronic metering system is equipped with a hectare meter and distance recorder which can be reset at the end of each paddock while keeping a total hectare count. When you've finished sowing an area the display will show the hectares sown.

If the distance button is pushed the distance traveled will be displayed.

If the speed button is pressed while moving the ground speed will be displayed.

TO RESET YOUR HECTARE METER

PRESS **AREA** Display shows the current hectares recorded.

PRESS **RESET** and hold for 3 seconds. Display will momentarily show total accumulated hectares then Show 0.000

WARNING SIGNAL OPERATION

The warning beeper sounds when the metering system is having trouble delivering at the rate entered. Usually it is caused by incorrect calibration or fixed parameters figures entered, or traveling to fast or slow.

REMEDY

Check and correct fixed parameters, check and adjust calibration sequence, or adjust ground speed.

SINGLE BOX FIXED PARAMETERS

NOTE. Start all calibration with the display showing

OFF

DIST

- When pressed increases the figures up in tens or hundreds.

SPEED

- When pressed decreases the figures down in .ones or ones.

PRESS **ON/OFF** To show **OFF** on the display.

PRESS **CAL 2** Display shows **P 1**

PRESS **DIST** Display shows **2.280** or **.817** (Jockey wheel)

PRESS **DIST** to increase in increments of .100 or **SPEED** to decrease in increments of .01.

PRESS **CAL 2** Display shows **P 2**

PRESS **DIST** Display shows **3.510** for 3.6m drill and **2.783** for 3.0m drill.

PRESS **DIST** to increase in increments of .100 or **SPEED** to decrease in increments of .001.

PRESS **CAL 2** Display shows **P 3**

PRESS **DIST** Display shows **40** or **20** if fitted with jockey wheel.

PRESS **DIST** to increase in increments of 10 or **SPEED** to decrease in increments of 1.

PRESS **CAL 2** Display shows **P 4**

PRESS **DIST** Display shows which is your target seeding rate in Kg/Ha

PRESS **DIST** to increase in increments of 10 or **SPEED** to decrease in increments of 1.

PRESS **CAL 2** Display shows **P 5**

PRESS **DIST** Display shows **150** (minimum motor speed)

PRESS **DIST** to increase in increments of 100 or **SPEED** to decrease in increments of 1.

PRESS **CAL 2** Display shows **OFF**